

SkyVac Internal 37 Model Assembly/User Guide
Aug 2014



SkyVac Assembly



Always use the Filter to protect the Motor

The drum cartridge must be kept in place at all times. Dust & debris will collect inside the bin
Alternatively fit filter bag with drum filter to collect debris inside the bag
this will also give ultra fine filtration
KEEP FILTER CLEAN



Push the long flexi hose cuff into vac port



Screw other end of hose (anti clockwise) into black cuff that fitted to one of your carbon fibre tubes






Push blue tool holder onto end pole



Connect poles together to the desired height



It is **Unnecessary** to push together hard they may stick



Push end cuff over your base pole



Select end tool to suit application

GOOD PRACTISE

Don't

Force the suction pole joints together.
Ensure the joints are free from dust and grit before putting together. Wipe the joints with a damp cloth. Grit can lock the joints up!

Do's

Occasionally spray the carbon fibre joints with Silicone Spray
Keep filters clean in your vacuum to keep retain suction power
When connecting poles together ensure they are free from grit and debris to prevent premature wear.

See your dealer for spare dust bags and specialist end tool not included is the standard kit

SPECIAL END TOOL S ASK DEALER FOR DETAILS

